

# Nextcom Bluetooth (BT) Speaker Mic User Guide



To turn **ON** the BT MIC, press the Power on/off button and hold it for a few seconds until you hear a beep tone. Release the button and see the blinking blue LED on the back. To turn **OFF** the BT MIC, press and hold the button for 5 seconds.

**Prepare Radio for Bluetooth Pairing** - Press Radio **MENU** (Green Button), Go to **SETTINGS** (Handheld radio uses Arrow buttons and Green button, Mobile radio uses only the Green button). Select **BLUETOOTH**, Enable or **OPEN** Bluetooth DETECTING device (GREEN button), wait to scan the devices available in range. Select the device you want to pair to **Nextcom**.

**Steps to Pair the BT Microphone** - With the power **OFF**, hold the power button down for 8 seconds minimum. A flashing blue/red light indicates pairing mode. Keep the BT mic near the pairing radio. The BT microphone will appear as a **Nextcom** device on the radio menu - select this device to pair. When the BT lights turn to a blue-only color, pairing is successful.

Press PTT button to talk, release PTT button to listen.

Press Volume+ and Volume- buttons to control the speaker output volume (long press)

LED Indicator Shows:	NEXTCOM FLEX BT Mic:
Light is not on	Power is OFF
RED/BLUE flashing alternately	In PAIRING Mode
BLUE flashing slowly	Pairing Confirmed/Normal Operation
RED flashing	Charging
RED solid	Charging complete

Charging Time	Approx. 2 Hours
Standby Time	Approx. 60 Hours
Operating Conditions	-15 to 50C

Contact Nextcom for assistance  
[Book a meeting online](#)  
 Call: (800) 909-6290 |  
 Email: [service@nextcommobile.com](mailto:service@nextcommobile.com)